

1. Modem Installation

Important Note: Do NOT install your modem until you are notified by Westelcom that your DSL service is ready.

1. Install filters on all phone jacks you will be using for DSL.
2. Remove all the contents from the box.
3. Connect the AC power adapter to the circle end of it to the modem (1) and the other end to the wall outlet.
4. Connect one end of the phone cord to the modem labeled ADSL (4) and the other to a wall jack or filter side labeled HPN/DSL.
5. Connect one end of an Ethernet cable (one that looks like a phone cord but bigger) to the back of the modem (3) and the other end to the jack of your Ethernet port on your computer. (The Ethernet port is the one that looks like a phone jack only bigger.)
6. Turn your modem and computer on.
7. The ADSL light will blink as it is searching for the DSL service. Once the light is solid the DSL is up.
8. The PC light will be solid when your computer is turned on, signifying that your Ethernet port is connected to the DSL modem successfully.
9. The TX and RX lights on the modem are the transmit and receive lights, respectfully. These will blink once you start using the DSL service.

Note: You will notice you have an extra cable left over. You will not need to use this cable.



Back of your modem will look like this.

**If you have a zyxel modem, console port (#2) will not be present*

2. Next you will need to configure your Network Settings

Instructions for MAC

1. Go to **Apple Menu > Control Panel > TCP/IP**
2. Click on the **Connect Via** drop down and select Ethernet.
3. Click on the **Configure** drop down and select manually.
4. Click in **IP address** box and enter in your IP address
5. Click on **Subnet Mask** box and enter in the subnet mask.
6. Click on **Router Address** box and enter in your gateway address.
7. Click on **Name Server** box and enter in the DNS numbers (press return after 1st address is in and then enter 2nd address).
8. Click on the **Close** box and say yes to save changes.

Network Settings You Will Need

IP Address: _____
Subnet: _____
Gateway: _____
DNS 1: _____
DNS 2: _____

Westelcom's



Instructions for Installation

Customer Name: _____

Install Date: _____

Your Ethernet Modem Box Includes:

1. Ethernet Modem
2. RJ11 cord. This is the standard telephone cord.
3. Ethernet Cable. This is the cable that looks like a regular phone cord but has a bigger plug.
4. AC Power Adapter
5. Console Cable. This is the 9 pin serial cable. You will not need to use this cable for anything.